

PLAZMAMAN.COM

Ph: +61 2 9725 1728 Email: sales@plazmaman.com

PLAZMACLAMPS

Fitting guide

1. Use grease / Vaseline on O-rings for initial installation.
2. Anti-seize compound is recommended on M5 threads for prolonged use and ease of release.
3. Do not over tighten the 2 clamp bolts. A firm tighten with the spring washers in place is sufficient.
4. ****WARNING** Do not leave orings exposed without a clamp. Leave in box until ready to install clamp. O-ring damage can result**