

NISSAN NAVARA / PATHFINDER PIPE INSTALLATION GUIDE

Please note the later manufactured vehicles have a “retaining clip” on the front end of the original pipe. The original clip removed requires the plastic tabs to be removed then the clip can be detached. Reuse the clip on the specially machined alloy o-ring fitting.

Please check the your original pipe matches the photos below to make sure you have the correct pipe. When installing the pipe on the vehicle you must remove the factory air muffler assembly (that is attached to the turbocharger outlet) from the vehicle. Some mechanical experience is required to install this pipe.

