

PLAZMAMAN

2JZ-GTE CAM COVERS INSTALLATION INSTRUCTIONS

Parts supplied

2 x cam covers

1 x oil cap

1 x bag of bolts and o-rings

Procedure

1. Remove the factory cam covers and studs.
2. Make sure the cylinder head surface is smooth and clean.
3. Install the supplied o-ring into the groove on the underside of the cover. There should be approx. equal amount of o-ring protruding from each side of the front cutout. Trim the overhanging o-ring with a blade so that it is flush with the opening in the front of the cover.
4. Use a small dab of silicone/sealant to stick the trimmed ends of the o-ring to the cover.
5. Place a liberal amount of silicone/sealer on the front cam cap, so that the cover will squash it down and seal when installed.
6. Install the covers onto the cylinder head using the M6 x 16 bolts supplied.
7. The rear breather holes are machined to dash 12 thread.
8. The filler cap is machined to dash 16 thread. If you do not wish to use the supplied oil cap, a dash 16 fitting will screw into this hole.
9. Once installed, start engine and thoroughly inspect for any leaks.



