

PLAZMAMAN

3RZ BILLET FUEL RAIL INSTALLATION INSTRUCTIONS

Parts supplied

- 1 x fuel rail
- 2 x mounting brackets
- 4 x bolts and washers
- 4 x injector collars
- 5 x fuel fittings

Procedure

1. Remove factory fuel rail and injectors
2. Make sure manifold and injectors are clean before installation
3. Install mounting brackets onto the cylinder head using the M8 bolts and.
4. Install the 2 x -8AN blockoff plugs into each end of the rail.
5. Install the injectors into the fuel rail using a small amount of Vaseline to lubricate the o-rings. This rail and setup can only be used for full length injectors.
6. Install the injector collars into the injectors bores on the cylinder head.
7. Install the rail and injector assembly onto the cylinder head, using a small amount of Vaseline to lubricate the o-rings.
8. Align the brackets to the rail and attach it using M6 bolts.
9. Install other fuel fittings, making sure they are tightened firmly. The bosses on the top are machined to -8AN. Fittings are supplied for these outlets.
10. We highly recommend starting your car immediately after installation, and thoroughly inspect that there are no leaks.