

## **Coyote Water Neck replacement directions**

Due to fitment requirements for the billet manifold, the factory thermostat housing and overflow fitting must be replaced with the supplied cast unit and fitting. Please follow these instructions:

1. Drain water from system and remove factory thermostat housing.
2. Remove gasket/O-ring from the bottom of the factory housing and replace it into the new housing supplied.
3. Add thread sealer and screw the 90-degree fitting into the top of the new cast outlet so that it points in the desired direction.
4. Re-attach the new cast housing to the engine and tighten to factory torque specifications.
5. Refill the coolant system and bleed to factory specifications.