



GTR BILLET INLET PLENUM INSTALLATION INSTRUCTIONS

INDIVIDUAL 6 THROTTLE TYPE

Parts supplied

6x M8x70mm studs

12x M8 nuts

1x billet inlet plenum

1x ¼ BSP to ½ inch barb fitting

3x 1/8 BSP to ¼ inch barb fitting

Procedure

1. Remove the factory inlet plenum
2. Remove all the top row of studs and replace with Plazmaman supplied M8x35 studs
3. Remove all the bottom row of factory studs and replace with studs that were removed from the top row.
4. Use the Plazmaman supplied nuts and washers to attach the billet inlet plenum.
5. To get the most out of this upgrade it is recommended that the engine be tuned with a re-mappable engine management system to make sure additional fuel and timing parameters are made.