

LS Series Billet Valve Cover Installation Instructions

Supplied Contents

2 x Billet Valve Covers

1 x Oil Cap

1 x bag of assorted O-rings and bolts

Installation Procedure

1: Insert large O-ring into the groove on underside of the covers.

2: Apply a small film of rubber grease to the O-ring.

3: Place valve cover into position.

4: Insert M6 bolts, making sure the O-ring is under the head of the bolt.

5: Tighten to factory specifications.

NOTES: - Front breather holes are machined to -12AN.

- Oil filler hole is machined to -16AN