



Ph: +61 2 9725 1728 Email: sales@plazmaman.com

PLAZMACLAMP TO FORD OEM THROTTLE BODY ADAPTOR

Fitting guide

1. Place the O-ring inside the adaptor, in the groove on the underside face.
2. Position the adaptor in the correct orientation, and add the 4 x spacers.
3. Add the M6 bolts through the adaptor and the spacers and attach it to the plenum.
4. For a billet intake, use 4 x 50mm long bolts. For an OEM intake, use 3 x 50mm long bolts, and 1 x 55mm long bolt on the front LH hole to hold the support bracket.



Ph: +61 2 9725 1728 Email: sales@plazmaman.com

PLAZMACLAMP TO FORD OEM THROTTLE BODY ADAPTOR

Fitting guide

1. Place the O-ring inside the adaptor, in the groove on the underside face.
2. Position the adaptor in the correct orientation, and add the 4 x spacers.
3. Add the M6 bolts through the adaptor and the spacers and attach it to the plenum.
4. For a billet intake, use 4 x 50mm long bolts. For an OEM intake, use 3 x 50mm long bolts, and 1 x 55mm long bolt on the front LH hole to hold the support bracket.



Ph: +61 2 9725 1728 Email: sales@plazmaman.com

PLAZMACLAMP TO FORD OEM THROTTLE BODY ADAPTOR

Fitting guide

1. Place the O-ring inside the adaptor, in the groove on the underside face.
2. Position the adaptor in the correct orientation, and add the 4 x spacers.
3. Add the M6 bolts through the adaptor and the spacers and attach it to the plenum.
4. For a billet intake, use 4 x 50mm long bolts. For an OEM intake, use 3 x 50mm long bolts, and 1 x 55mm long bolt on the front LH hole to hold the support bracket.

