

PLAZMAMAN
.com



Ph: +61 2 9725 1728 Fax: +61 2 9725 1722

SR20 Fuel Rail Fitting Instructions

Included in the kit are 3 x rail brackets marked 'R', 'M' and 'F'

- **F** = Front bracket
- **M** = Middle bracket
- **R** = Rear bracket

1) We recommend a test fit first without injectors. Attach brackets to fuel rail and nip up slightly so can they still move.

2) Fit rail to manifold (without injectors) to move brackets into correct position so they attach to the manifold

3) Remove the rail again tighten the stands up fully. Add required end hose fittings at this stage.

4) Use rubber lube/grease on o-rings. Carefully insert injectors and attach rail to manifold