

MAZDA RX7 SERIES 6-8 FITTING INSTRUCTIONS

1. Remove factory bumper and plastic supports.
2. Remove OEM intercooler and pipes.
3. Drill spot welds off factory metal support in front of radiator.
4. Sand remaining spot weld marks smooth with grinder or similar.
5. Bolt Plazmaman support in place. Check for straightness then run weld on top and bottom of support to secure in place. (Pic. 1)

WARNING: MUST BE WELDED DO NOT USE THE BOLTS ONLY

6. Using soft mallet, lightly tap edge of bodywork to allow fitment of end tanks. (Pic. 2)
7. Paint bare metal and welded surfaces.
8. Refit horns and earth straps.
9. Fit intercooler and pipes, taking care not to scratch polished pipes and intercooler end tanks. (Pic. 3)
10. Bolt plastic water bottle to battery upright using the supplied bracket.
11. Trim bumper bar back slowly until totally clear of intercooler.
12. Start vehicle and check for leaks.
13. Stand back and look. You have just fitted the sexiest looking intercooler kit on the market for the RX7 series 6-8



Pic. 1



Pic. 2



Pic. 3

INTENDED FOR OFF-ROAD USE ONLY

WWW.PLAZMAMAN.COM